

# WS900 Compact Weather Station

## User Guide



# Catalog

Product Brief .....	2
Product Technical Data.....	3
Product Dimensions.....	4-5
MODBUS RTU Communication Protocol .....	6-12

## WS900 Compact Weather Station

- ◆ **Product Brief**

YANTAI WS900 compact weather station integrates ten meteorological parameters, Ambient Temperature, Relative Humidity, Atmospheric Pressure, Wind Speed, Wind Direction, Optical Rainfall, Noise, Illumination/Solar Radiation (either-or), PM<sub>2.5</sub> and PM<sub>10</sub>, in one structure. It realizes 24 hours continuous online monitoring of outdoor meteorological parameters, and outputs these data to users through digital communication interface all at once.

- ◆ **Application**

- Meteorological Monitoring
- Micro Environmental Monitoring
- Grid Environment Monitoring
- Agricultural Meteorological Monitoring
- Meteorological Traffic Monitoring
- Photovoltaic Environment Monitoring
- Meteorological Monitoring of Wind Power Generation
- Smart City/Intelligent Light Pole Environmental Monitoring

- ◆ **Features**


- Small in size
- High integration
- Easy to install
- Protective cover with special process heat insulation treatment
- Support extended parameter measurement
- Integrated design
- Compact structure with no moving parts
- One year warranty

- ◆ **Product Technical Data**

Parameters	Measuring Range	Accuracy	Resolution	Sampling Frequency
Ambient Temperature	-40-85°C	±0.3°C@25°C	0.01°C	1HZ
Relative Humidity	0-100%RH	±3%RH	0.01%RH	1HZ


Wind Speed	0-40m/s	±0.3 m/s	0.01	10HZ
Wind Direction	0-359.9 °	±3°	0.1°	10HZ
Atmospheric Pressure	500-1100hPa	±0.5hPa	0.1hPa	1HZ
Optical Rainfall	0-200mm/h	±15%	0.2mm	1HZ
PM <sub>2.5</sub>	0-500ug/m <sup>3</sup> (Extensible 1000ug/m <sup>3</sup> )	±10% ug/m <sup>3</sup>	1ug/m <sup>3</sup>	1HZ
PM <sub>10</sub>	0-500ug/m <sup>3</sup> (Extensible 1000ug/m <sup>3</sup> )	±10% ug/m <sup>3</sup>	1ug/m <sup>3</sup>	1HZ
Illuminance	0-100KLux	±3%	10Lux	1HZ
Solar Radiation	0-2000W/m <sup>2</sup>	±5%	1W	1HZ
Noise	30-130dB	±1.5dB	0.1dB	1HZ
Operating Temperature	-40°C - 80°C			
Output	Standard product with RS485 interface, ModbusRTU; Customizable option SDI-12(Extra costs apply)			
Maximum Output Frequency	Passive Mode: 1/S Active Mode: 1/min			
Power Supply	DC9-24V			
Level of Protection	IP65			
Mounting Manner	Standard Product is sleeve fixed (Optional: matching parts, extra costs apply, see Accessory and Parts)			
Fixed Trestle	Optional: 1.5 meter, or 1.8 meter bracket (extra cost apply)			
Cable	3 meter cable line (Optional: 10 meter cable line available for extra cost )			
Customizable	Heating function			

◆ **Product Dimension**




◆ **Accessory and Parts**

**Flange Mounting Manner:**



**Bending Plate Mounting Manner:**



# MODBUS RTU Communication Protocol

(

## Apply to WS900 product )

Baud Rate: 9600

Data Bits: 8

Stop Bit: 1

Check Bit: None

### 1.1 CRC Instruction:

Among all the following instructions, the two bytes of CRC16 in MODBUS RTU protocol are as follows: the low byte comes before the high byte comes after.

In the following instructions, the assumed sensor address is 0xFF (the sensor default address is FF)

### 1.2 Return error code rule:

When receive error instruction (including CRC16 validation error), no error code are returned. It is considered to be a failure, when there is no return data, 200ms after the instruction is issued. Upper computer may resend instruction.

### 1.3 Standard MODBUS register declaration

Special Notice:

The quantity or length of the register in Modbus is two bytes with 16 bits as a unit (the high byte comes first, and the low bytes follws), instead of one byte with 8 bits as a unit.

User shall ensure in command, the address and quantity of register, are within the range specified by the system. Otherwise, the output of the sensor will be unpredictable.

Users shall ensure that the MODBUS command complies with the requirements of this manual in the software design of the upper computer, and the minimum query period supported is 1s/ time.

### Input register: read with function code 03

Address	Operation	Contents	Note
0x0001	Read-only	Noise, a hexadecimal number amplified by 10 times, such as 0x01193, means $403/10=40.3\text{dB}$	
0x0002	Read-only	Hydrogen Sulfide/TVOC, a hexadecimal number.	
0x0003	Read-only	SO <sub>2</sub> concentration, a hexadecimal. For example, 0x0172 indicates that SO <sub>2</sub> concentration is 370ppb.	
0x0004	Read-only	NO <sub>2</sub> concentration, a hexadecimal number. For example, 0x0036 indicates that NO <sub>2</sub> concentration is 54ppb.	
0x0005	Read-only	CO concentration, a hexadecimal number. For example, 0x0A00 indicates that CO concentration is 2560ppb.	
0x0006	Read-only	O <sub>3</sub> concentration, a hexadecimal number. For example, 0x0123 indicates that O <sub>3</sub> concentration is 291ppb.	
0x0007	Read-only	PM <sub>2.5</sub> concentration, a hexadecimal number. For example, 0x0172 indicates that PM <sub>2.5</sub> concentration is 370 $\mu\text{g}/\text{m}^3$ .	
0x0008	Read-only	PM <sub>10</sub> concentration, a hexadecimal number. For example, 0x0193 indicates that PM <sub>10</sub> concentration is 403 $\mu\text{g}/\text{m}^3$ .	
0x0009	Read-only	Ambient Temperature, a hexadecimal number add 40 then magnified 100 times. For example, 0x1B00 indicates $6912/100-40=29.12^\circ\text{C}$	
0x000A	Read-only	Relative Humidity, a hexadecimal number magnified by 100 times. For example, 0x1603 indicates $5635/100=56.35\%\text{RH}$ .	
0x000B	Read-only	Atmospheric Pressure, a hexadecimal number magnified by 10 times. For example, 0x2784 indicates $10116/10=1011.6\text{hPa}$ .	
0x000C	Read-only	Wind Speed, a hexadecimal number magnified by 100 times. For example, 0x0125 indicates $293/100=2.93\text{m/s}$	
0x000D	Read-only	Wind Direction, a hexadecimal number magnified by 10 times. For example, 0x0C14 indicates $3092/10=309.2^\circ$	The North points to the 0°
0x000E	Read-only	Continuous Rainfall, a hexadecimal number magnified by 10 times , For example, 0x0016 indicates 2.2mm.	



0x000F	Read-only	Solar Radiation, a hexadecimal number. For example,0x0172 indicates 370W/m <sup>2</sup> .	
0x0010	Read-only	Illumination, a hexadecimal number magnified by 100 times. For example, 0x0123 indicates 2.91.Klux.	
0x0011	Read-only	UV index	
0x0012	Read-only	CO2, a hexadecimal number. For example, 0x01F4 indicates 500ppm.	
0x0013	Read-only	Negative Oxygen Ion, a hexadecimal number shrunked by a factor of 10. For example, 0x01F4 indicates Negative Oxygen Ion number is5000.	
0x0014-0x001f	Read-only	Keep	
0x0020	Read-only	Electronic compass, a hexadecimal number. For example,0x0036 indicates currently pointing to 54°	The North points to the 0°
0x0021	Read-only	Pitch angle 1	Custom-made
0x0022	Read-only	Pitch angle 2	Custom-made
0x0023	Read-only	Pitch angle 3	Custom-made
0x0024	Read-only	longitude-1	Custom-made
0x0025	Read-only	longitude-2	Custom-made
0x0026	Read-only	latitude-1	Custom-made
0x0027	Read-only	latitude-2	Custom-made
0x0028	Read-only	Altitude	Custom-made

#### 1.4 Example

**The following is an example of how to use Modbus RTU commands to access system registers:**

1. Read multiple input registers (10 real time data) command

Send: FF 03 00 01 00 10 00 18

FF	03	00 01	00 10	00 18
System Address	Function Code	Register Address	Number of Registers	CRC16 check digit automatically generated by

				software
--	--	--	--	----------

Answer: FF 03 20 02 08 00 00 00 00 00 00 00 00 00 00 00 11 00 14 1A 57 0C 5F 27 83 00 11 0C 14  
00 01 00 00 01 26 2C 3C

FF	03	0A	02 08 00 00 00 00 00 00 00 00 00 00 00 00 00 00 11 00 14 1A 57 0C 5F 27 83 00 11 0C 14 00 01 00 00 01 26	2C 3C
System Address	Function Code	The number of bytes in a data segment	Segment Data	CRC16 check bit

Data parse:

$$0X0208=0x02*256+0x08=520$$

$$\text{Noise}=520/10=52\text{dB}$$

$$0x0011=17$$

$$\text{PM2.5}=17 \text{ ug/m}^3$$

$$0x0014=20$$

$$\text{PM10}=20 \text{ ug/m}^3$$

$$0x1A57= 0x1A * 256 + 0x57= 6743$$

$$\text{Ambient Temperature} = 6743/100-40=27.43^\circ\text{C}$$

$$0x0C5F= 0x0C * 256 + 0x5F= 3167$$

$$\text{Relative Humidity}=3167/100=31.67\%\text{RH}$$

$$0x2783= 0x27 * 256 + 0x83= 10115$$

$$\text{Atmospheric Pressure}=10115/10=1011.5\text{hPa}$$

$$0x0011=17$$

$$\text{Wind Speed}=17/100=0.17\text{m/s}$$

$$0x0C14=0x0C * 256 + 0x14= 3092$$

$$\text{Wind Direction}=3092/10=309.2^\circ$$

$$\text{Rainfall}=1/10=0.1\text{mm}$$

$$0x0109=0x01*256+0x09=265$$

$$\text{Illumination}=265/100=2.65\text{klux}=2650\text{lux}$$

## 2. Read a single input register command

Send: FF 03 00 09 00 01 41 D6

FF	03	00 09	00 01	41 D6
System Address	Function Code	Register Address	Number of Registers	CRC16 check digit automatically generated by

				software
--	--	--	--	----------

Answer: FF 03 02 1A 57 DB 0E

FF	03	02	1A 57	DB 0E
System Address	Function Code	The number of bytes in a data segment	Segment Data	CRC16 check bit

Data parse:

$$0x1A57 = 0x1A * 256 + 0x57 = 6743$$

$$\text{Ambient Temperature} = 6743/100 - 40 = 27.43^\circ\text{C}$$

### 3. Read address register command

Send: 00 03 00 00 00 01 85 DB

00	03	00 00	00 01	85 DB
	Function Code	Register Address	Number of Registers	CRC16 check digit automatically generated by software

Answer: 00 03 02 00 01 44 44

00	03	02	00 01	44 44
	Function Code	The number of bytes in a data segment	Segment Data	CRC16 check bit

Segment data 0x0001 = 01    System address 01

### 4. Modify internal register (system address) command (change the address to 0x33)

Send: 00 06 00 00 00 33 C8 0E

00	06	00 00	00 33	C8 0E
	Function Code	Register Address	New Address	CRC16 check bit

Answer: 00 06 00 00 00 33 C8 0E (indicates that the modification is successful)

00	06	00 00	00 33	C8 0E
	Function Code	Starting Address	New Address	CRC16 check bit

5. Set the rainfall accumulation time

Send: 00 06 01 07 00 0A B8 21

00	06	01 07	00 0A	B8 21
	Function Code	Register Address	Cumulative Time (10 Minutes)	CRC16 check bit

Answer: 00 06 01 07 00 0A B8 21 (indicates that the modification is successful)

00	06	01 07	00 0A	B8 21
	Function Code	Starting Address	Cumulative Time (10 Minutes)	CRC16 check bit

**Note: This device factory default setting is the continuous accumulation unclear 0 mode. When the rainfall accumulation time is set to 0, the device does not automatically clear the rainfall, and it has been accumulated continuously. The rainfall can be reset to zero by restarting the power or resetting the rainfall accumulation time ( sending command 00 06 01 07 00 00 38 26 cleared to 0, regularly)**

6. Set magnetic decrement correction (only for electronic compass function)

Send: 00 06 01 06 00 05 A9 E5

00	06	01 06	00 05	A9 E5
Station Number	Function Code	Register Address	Correction Angle	CRC16 check bit

Answer: 00 06 01 06 00 05 A9 E5 (indicates that the modification is successful)

00	06	01 06	00 05	A9 E5
Station Number	Function Code	Register Address	Correction Angle	CRC16 check bit

Correction Angle Implication

The high eight digits indicate the direction of correction,0x00 represent positive correction, 0x01 represent negative correction.

The low eight digits indicate the angle of the correction

Example: 0x00 05 represent that require to add 5 degree to the output

0x01 03 represent that require to reduce 3 degree to the output

7. Read the latitude and longitude information

Send AT+GPS#

Answer

GPS:36.12345,N;114.12345,E;2019-01-01,D;10:20:00,T;0040.2,H#

Supplementary agreement: (the default device address is FF)

---

Active reporting period (Register Address 0x01 0A) Unit is min, 0 indicates no reporting  
00 06 01 0A 00 0A 29 E2 (Set the active reporting period to 10 minutes)

Active reporting length (Register Address 0x01 0B)  
00 06 01 0B 0C 02 7C E4 (Active reporting register address 0C-0D)

Baud Rate (Register Address 0X0102)  
00-06 respectively represent 2400、4800、9600、19200、38400、57600、115200

**00 06 01 02 00 02 A9 E6 (Set the baud rate to 9600, non-professionals shall not change it by themselves)**

Handan Yantai Import and Export Co., Ltd.  
Room 102, Floor 1, Block C, Building 1, No. 19,  
Hexie Street, Handan Economic Development  
Zone, Hebei Province.China.